



Drilling Wedges - Subs

Sub, Water Swivel & Hoisting Plug



Part Number	Description
93-51-200	SUB EW R/P TO BW/L R/P
93-51-201	SUB AW R/P TO BW/L R/P
93-51-202	SUB AW R/P TO NW/L R/P
93-51-203	SUB AW R/P TO HW/L R/P
93-51-204	SUB AW R/P TO HWT R/P
93-51-211	SUB AW R/P TO BT R/P
93-51-212	SUB AW R/P TO NT R/P
93-51-214	SUB AW R/P TO HT R/P
93-51-215	SUB AW R/P TO HM R/P
93-51-301	SUB BW R/P TO BW/L R/P
93-51-302	SUB BW R/P TO NW/L R/P
93-51-303	SUB BW R/P TO HW/L R/P
93-51-304	SUB BW R/P TO HWT R/P
93-51-310	SUB BW R/P TO BT R/P
93-51-311	SUB BW R/P TO NT R/P
93-51-312	SUB BW R/P TO NM R/P
93-51-313	SUB BW R/P TO HT R/P
93-51-401	SUB NW R/P TO NW/L R/P
93-51-402	SUB NW R/P TO HW/L R/P
93-51-411	SUB NW R/P TO NT R/P
93-51-413	SUB NW R/P TO HT R/P

Sub, Wedging and Fishing Tools



Part Number	Description
93-55-300	SUB BW/L R/B TO EW R/P
93-55-301	SUB BW/L R/B TO AW R/P
93-55-302	SUB BW/L R/B TO BW R/P
93-55-315	SUB BWL R/B TO AX R/P
93-55-310	SUB BT R/B TO EW R/P
93-55-311	SUB BT R/B TO AW R/P
93-55-311	SUB BT R/B TO AW R/P
93-55-312	SUB BT R/B TO BW R/P
93-55-401	SUB NW/L R/B TO AW R/P
93-55-401LG	SUB NW/L R/B TO AW R/P LRG BOR
93-55-402	SUB NW/L R/B TO BW R/P
93-55-402LG	SUB NW/L R/B TO BW R/P LRG BOR
93-55-403	SUB NW/L R/B TO NW R/P
93-55-417	SUB NW/L R/B TO NX R/P
93-55-411	SUB NT R/B TO AW R/P
93-55-412	SUB NT R/B TO BW R/P
93-55-413	SUB NT R/B TO NW R/P
93-55-501	SUB HW/L R/B TO AW R/P
93-55-502	SUB HW/L R/B TO BW R/P
93-55-503	SUB HW/L R/B TO NW R/P
93-55-511	SUB HT R/B TO AW R/P
93-55-512	SUB HT R/B TO BW R/P
93-55-513	SUB HT R/B TO NW R/P
93-55-611	SUB HWT R/B TO AW R/P
93-55-612	SUB HWT R/B TO BW R/P
93-55-613	SUB HWT R/B TO NW R/P

** R/B = Rod Box R/P = Rod Pin **

