

Drilling & Exploration - Sub Parts

Sub, Casing



Part Number

Description

93-56-300	SUB BW/L R/B TO AW CSG/P
93-56-301	SUB BW/L R/B TO BW CSG/P
93-56-302	SUB BW/L R/B TO NW CSG/P
93-56-310	SUB BT R/B TO AW CSG/P
93-56-311	SUB BT R/B TO BW CSG/P
93-56-312	SUB BT R/B TO NW CSG/P
93-56-320	SUB BW CSG/B TO N BIT-THRD/P
93-56-321	SUB BW CSG/B TO NW/L R/P
93-56-322	SUB BW CSG/B TO NTW R/P
93-56-400	SUB NW/L R/B TO BW CSG/P
93-56-401	SUB NW/L R/B TO NW CSG/P
93-56-402	SUB NW/L R/B TO HWT CSG/P
93-56-410	SUB NT R/B TO BW CSG/P
93-56-411	SUB NT R/B TO NW CSG/P
93-56-412	SUB NT R/B TO HWT CSG/P
93-56-420	SUB NW CSG/B TO H BIT-THRD/P
93-56-421	SUB NW CSG/B TO HW/L R/P
93-56-422	SUB NW CSG/B TO HWT CSG/P
93-56-500	SUB HW/L R/B TO NW CSG/P
93-56-501	SUB HW/L R/B TO HWT CSG/P
93-56-502	SUB HW/L R/B TO PWT CSG/P
93-56-510	SUB HT R/B TO NW CSG/P
93-56-511	SUB HT R/B TO HWT CSG/P
93-56-512	SUB HT R/B TO PWT CSG/P
93-56-601	SUB HWT CSG/B TO PWT CSG/P
93-56-620	SUB HWT CSG/B TO PWL/BIT THRD
93-56-621	SUB PWT CSG/B TO PW CSG/P
93-56-622	SUB PW CSG/B TO PWT CSG/P

Sub, Rod



Part Number

Description

93-52-100	SUB EX R/B TO EW R/P
93-52-101	SUB EX R/B TO EW R/B
93-52-200	SUB AW R/B TO EW R/P
93-52-201	SUB AW R/B TO BW R/P
93-52-202	SUB AW R/B TO AX R/P
93-52-210	SUB AX R/B TO AW R/P
93-52-300	SUB BW R/B TO AW R/P
93-52-301	SUB BW R/B TO NW R/P
93-52-400	SUB NW R/B TO BW R/P
93-52-410	SUB NX R/B TO BW R/P
93-52-412	SUB NT R/B TO NW/L R/P
93-53-100	SUB EW R/P TO EW R/P
93-53-200	SUB AW R/P TO AW R/P
93-53-201	SUB AW R/P TO BW R/P
93-53-210LG	SUB AX R/P TO AW R/P LRG BORE
93-53-300	SUB BW R/P TO BW R/P
93-53-301	SUB BW R/P TO NW R/P
93-53-400	SUB NW R/P TO NW R/P
93-53-410	SUB NX R/P TO BW R/P

** R/B = Rod Box R/P = Rod Pin **

North America 1-800-669-3542
International +1-705-647-8138

PAGE: DE31



www.timeltd.ca

